

1                                   **“APPARATUS AND METHOD FOR**  
2                                   **REMOTE ADMINISTRATION OF A PC-SERVER”**

3  
4                                   **CROSS REFERENCE TO RELATED APPLICATION**

5                                   This application is a continuation-in-part of pending US Patent  
6 application Serial No. 09/492,090 filed on January 27, 2000, the entirety of which is  
7 incorporated herein by reference.

8  
9                                   **FIELD OF THE INVENTION**

10                                The present invention relates to communications interfaces and  
11 methods for use for remote administration of a personal computer being used as a  
12 server. A display emulator, input emulator and serial I/O are provided for forwarding  
13 BIOS level console output and for receiving emulation input data.

14  
15                                **BACKGROUND OF THE INVENTION**

16                                Generally, servers operate unmanned and provide a common service  
17 to a plurality of manned computers, all connected by a network of some sort.  
18 Typically, a server maintains one or more local disks and services application  
19 requests from remote computers such as reading and writing to shared directories.  
20 Specifically engineered servers include those by Sun Microsystems, based on  
21 Motorola 680x0 or SPARC microprocessors (from Sun Microsystems, Inc., Mt. View  
22 CA). Usually, these servers utilize a Unix operation system, and utilize a hardware  
23 architecture and software which is easily remotely administrated, including the  
24 provision for serial I/O at the boot level for the output of character-based diagnostic  
25 messages. Due to the ability to route a server's console output through a serial  
26 device to an administrating terminal, it is usual to omit a video display (running

1 headless) and omit a keyboard input. Sometimes one set of video and keyboard  
2 interfaces may be switched among many servers locally, or through a network.

3                   Increasingly, lower cost Intel Pentium-based microprocessor personal  
4 computers are now also being implemented as servers (referred to herein as a PC-  
5 Server). However, such a PC-Server, equipped with a conventional Basic  
6 Input/Output System (BIOS), cannot be as readily administered remotely.

7                   In such IBM PC and compatible Personal Computers (PCs), the PC-  
8 BIOS provides the lowest level interface and hardware drivers for peripheral  
9 input/output (I/O) devices, such as video output, keyboard input and media I/O. The  
10 video output during boot up at the BIOS level is generally ASCII character based as  
11 the hardware and memory intensive graphical characteristics of a Graphical User  
12 Interface (GUI) requires application programs and capable peripherals (e.g. video  
13 display).

14                   On boot up, such a PC-BIOS outputs certain status information to a  
15 local video display but, unlike the engineered servers, and except for custom  
16 designs, it is not generally capable of output other than through the local video  
17 display. Such information includes a character display confirmation of the  
18 successful operation and identification of the video display device, the amount of  
19 RAM and the current status of BIOS settings such as the processor type, hard drive  
20 specifications, and the presence and type of other installed I/O devices.  
21 Opportunities are provided to a user to interrupt the boot process with a keyboard  
22 stroke and thereby modify the system PC-BIOS configuration or peripherals  
23 settings.

1           Once the operating system is running however, application programs  
2 are available to enable a remote user to access and manipulate certain of the  
3 computer settings. Such an application program is pcAnywhere, supplied by  
4 Symantec Corporation, of Cupertino, CA. The pcAnywhere program and protocol  
5 provides communication components which enable remote control capabilities  
6 through a phone line or an internet interface. The user installs and runs a version of  
7 the pcAnywhere program on both the remote and the host PCs. Once loaded and  
8 running, the user at the remote PC can remotely access data and control  
9 applications located on the host PC. The usual communication protocol between  
10 the PCs is the TCP/IP Network Protocol, accessed through an internet connection.

11           However, after a reboot, control is not regained until the operating  
12 system is again loaded and the pcAnywhere application program is running again,  
13 long after any diagnostic messages are past. In a diagnostic situation, generally to  
14 resolve the situation which prompted a restart of the PC in the first place, monitoring  
15 of the BIOS level information is the most pertinent.

16           Further, during normal use of the PC occasionally, extraordinary  
17 system level errors occur and messages are displayed directly in a default character  
18 or text format on the normal graphical interface video display. Again, these are only  
19 displayed on the local video display.

20           In US Patent 5,214,785 to Fairweather, a controller is disclosed for  
21 remote operation of a host PC, particularly for remotely initiating host PC application  
22 programs, downloaded to the controller for operating a plurality of external  
23 peripherals – like household line-powered devices - even after the host PC is

1 powered down. Fairweather envisions powering the host PC through a controller  
2 peripheral for permitting hard reboot of the host PC via interruption of the PC's  
3 power. The controller operation is dictated through software downloaded from  
4 corresponding applications started by the controller and running on the host PC.  
5 The controller is provided physically external to the PC and comprises a  
6 microprocessor, ROM-resident software, an RS-232 serial I/O communication  
7 device, and a keyboard emulation interface. An application program may be started  
8 through commands issued through the emulated keyboard interface. Once running,  
9 host PC application program can writing ASCII commands to the controller or  
10 download a program to the controller's ROM through the host PC's RS-232 port.  
11 Fairweather acknowledges that once the host PC has been brought up to operating  
12 system level, then Fairweather's RS-232 application program may be started.  
13 Accordingly, Fairweather's controller operates "blind" until their corresponding  
14 application program is operational.

15 Others have implemented external hardware which connect to the  
16 video output of the PC's own video card and thus are capable of rebroadcasting the  
17 data that appears on a local terminal, including boot screens, via modem to a  
18 remote user running a compatible operating system such as Windows 9X (Microsoft  
19 Corporation). In other words, what is fed to the monitor is rebroadcast. The remote  
20 system operates pcAnywhere protocol to enables remote control of the hardware.  
21 The remote user is limited to the information which is displayed and not to the  
22 additional yet useful non-displayed POST diagnostic information.

1 Applicants are unaware of means, either in the prior art, including the  
2 teachings of Fairweather, for administering a typical BIOS-equipped PC through  
3 boot without actually monitoring a local video display or manipulating a local  
4 keyboard. Accordingly, it is not known to perform administration, troubleshooting or  
5 for maintenance on such a PC-Server including the ability to review system level  
6 messages or reset the system, including to address the installed peripherals or to  
7 command selection of a different boot device.

8 Accordingly, for a PC-Server which has a standard BIOS and is  
9 headless, there has not yet been a satisfactory solution for the demonstrated need  
10 to provide remote console output to effect proper PC-Server administration.

11

## 12 SUMMARY OF THE INVENTION

13 Generally, the invention is an administration adapter for a PC-server  
14 which implements communications to a remote user for remote viewing of data  
15 available on the PC-Server's bus and for enabling remote keyboard input, even  
16 during re-boot sequence of the PC-server. The PC-Server recognizes the  
17 administration adapter as comprising both an emulated display adapter and an RS-  
18 232 serial communications device. Preferably the emulated display adapter  
19 emulates both the video frame buffer and video controller register. Further, power  
20 up self test or POST data is also written from the bus to the administration adapter  
21 so that it and display data is converted to a serial data stream and is serially output  
22 to the remote user. In return, remote user keyboard commands are received by the  
23 serial device, are converted to compatible scan codes (emulating the PC-Server's

1 keyboard) and are routed to the PC-Server's input interface as though the  
2 commands were issued with a local input interface such as a keyboard.

3 Accordingly, in a broad method aspect of the invention, a method of  
4 remote user administration of a PC-Server having a data bus for read and write  
5 functions to peripherals including a display adapter, and having at least one  
6 keyboard input interface, comprising the steps of:

- 7 • providing a peripheral adapter on the bus which emulates the  
8 display adapter to an extent necessary to receive display data from  
9 the bus and which has a communications device for transmission  
10 of data between the PC-Server and the remote user;
- 11 • determining if the bus has written display data to the adapter;
- 12 • extracting the display data from the adapter and converting the  
13 data from a graphical format as necessary ;
- 14 • transmitting the display data via the communications device to the  
15 remote user;
- 16 • receiving input commands from the remote user via the  
17 communications device; and
- 18 • transmitting the received input commands to and in a form  
19 compatible with the input interface.

20 Preferably, the adapter emulates the video frame buffer of a display  
21 adapter, the display data is converted to ANSI escape sequences before  
22 transmission to the remote user, the input commands are converted into keyboard  
23 input interface compatible scan codes before transmission to a keyboard input

1 interface, and that the display data and keyboard commands are communicated via  
2 a serial I/O device.

3 More preferably, the adapter further emulates the I/O port for the BIOS  
4 power up self test (POST) so that the status of the last write may be extracted and  
5 transmitted to the remote user for demonstrating the status of the most recent PC-  
6 Server BIOS initiation.

7 The method the invention is achieved using novel apparatus, which in  
8 a broad aspect comprises:

- 9 • an adapter on the bus which emulates a display adapter to an  
10 extent necessary to receive display data from the PC-Server bus;
- 11 • means for extracting the display data from the adapter;
- 12 • means for transmitting the display data to a remote user;
- 13 • means for receiving data from the remote user representing input  
14 interface commands to the PC-Server; and
- 15 • means for transmitting the input commands to and compatible with  
16 the PC-Server input interface.

17 Preferably, the adapter emulates at least the video frame buffer and  
18 video controller registers for a display adapter.

19 More preferably, the means for transmitting console output and  
20 receiving input commands is a serial communications device, the means for  
21 retrieving character data from the frame buffer and converting it for serial  
22 transmission is a microprocessor and a microprocessor converts the input

1 commands to a form such as scan codes compatible with the PC-Server keyboard  
2 input interface.

3 The method and apparatus of the present invention also makes it  
4 possible to route textual data to a speech synthesizer at the boot level, which  
5 heretofore has required the operating system to be fully loaded to provide any text-  
6 to speech synthesis.

7

### 8 BRIEF DESCRIPTION OF THE FIGURES

9 Figure 1 is a schematic of the interface of an implementation of the  
10 administration adapter of the present invention and the system board of the PC-  
11 Server;

12 Figure 2 is a screen display at a console of the remote user illustrating  
13 the administration adapter providing a help list of possible keyboard commands to a  
14 PC-Server;

15 Figure 3 is a screen display at a console of the remote user illustrating  
16 the PC-Server textual display data appearing at the console and poised to accept  
17 an emulated keyboard command to reset or reboot the PC-Server;

18 Figure 4 is a screen display at a console of the remote user illustrating  
19 the PC-Server textual display data appearing at the console after the reset  
20 according to Fig. 3 and illustrating the BIOS level console output;

21 Figure 5 is a screen display at a console of the remote user illustrating  
22 a configuration option screen upon reset of the administration adapter;



1               Figure 6 is a schematic diagram illustrating the relationship between  
2     the 68HC11 microprocessor, the UART, the modem registers and the DUART;

3               Figure 7 is a table of mnemonics for enabling the emulation of a PC-  
4     Server keyboard with individual keystrokes; and

5               Figure 8 is a table of command choices available for configuration of  
6     the administration adapter.

7

## 8               DETAILED DESCRIPTION OF THE PREFERRED EMBODIMENT

9               In this description, references to a PC-server are made in the context  
10    of an Intel Pentium-based or IBM-compatible personal computer however, as it will  
11    become evident, the invention is equally applicable to any microprocessor-based  
12    computer which is not designed or equipped to output to a remote console at the  
13    hardware and BIOS level, thereby precluding remote system administration.

14            A BIOS of a PC-Server is not generally equipped for serial device-to-  
15    console communications. Without either a console (video display) or local keyboard  
16    input, the PC-Server is incapable of being remotely supervised or administered until  
17    such time as the operating system is fully loaded. For the purposes of the  
18    description of the preferred embodiment, it is assumed that the PC-Server does not  
19    have either a local video display or keyboard.

20            As shown in Fig. 1, and in a much simplified form, the PC-Server  
21    comprises a system board 1 supporting a Pentium microprocessor 2, RAM 3, a  
22    BIOS 4, and a bus 5. Common bus types include the older ISA (8-16 bit Industry  
23    Standard Architecture) and the PCI (32-64 bit Peripheral Component Interconnect)

1 which enable communication between on-system board and peripheral devices.  
2 The microprocessor 2, BIOS 3 and RAM 4 are connected to a display adapter  
3 through the bus 5 and are connected through a keyboard controller 7 to a keyboard  
4 input interface as one form of input interface 6. A PC-Server may have one or more  
5 input interfaces 6. A reset switch 8 is provided for a hard reset of the system board  
6 1.

7 Remote administration of the PC-Server is provided through an  
8 administration adapter 10 which emulates a display adapter on the bus 5, converts  
9 it to a stream compatible for transmission to a remote user at a remote console 9.

10 Video emulation herein comprises emulation of a combination of the  
11 components normally found in a video board (e.g. in the case of VGA: the video  
12 controller registers or a subset or superset thereof, video memory, and VGA BIOS  
13 firmware) that satisfy the host computer as to the presence of a video board and a  
14 method of transmitting or otherwise outputting the information stored in the video  
15 memory by the host computer, whether character or graphic or a combination of  
16 the two, typically via means other than a conventional video signal, regardless of  
17 whether the device also produces a conventional video signal.

18 Accordingly, the administration adapter 10 satisfies the PC-Server of  
19 the presence of a display adapter (if no other is present) and provides means for  
20 communicating and receiving data other than the conventional video signal.  
21 Communicated data includes data stored in video memory by the PC-Server. Data  
22 may be textual, graphical or a combination of both. The administration adapter 10  
23 comprises a circuit board 11 having a bus connection 12 which is hardware

1 compatible with the system board bus 5. Having reference to Figs. 2 – 4, the remote  
2 user is able to control and monitor the PC-Server. As described in greater detail  
3 below, Fig. 3 illustrates the ability of the administration adapter 10 to provide a  
4 range of options to the remote user. As shown in Fig. 3 a remote user has chosen  
5 to reboot the PC-Server. Fig. 4 illustrates the display of the display information as  
6 the BIOS performs its system and peripherals checks. The illustrated display is a  
7 simple one, typically based on a text mode compatible between the PC-Server and  
8 the administration adapter 10.

9           To minimize the administration adapter's onboard microprocessor  
10 requirements, the simplest and lowest memory-intensive display adapter emulation  
11 was selected for the preferred embodiment. To all intents and purpose, the  
12 administration adapter 10 is recognized by the BIOS 4 as an MDA display adapter.  
13 The administration adapter achieves this by emulating the MDA's registers and  
14 behavior including the 6845 CRT video controller and the "video" memory or frame  
15 buffer. Thus the administration adapter 10 emulates a display adapter on the PC-  
16 Server and is targeted for receiving system board console output which is available  
17 on the bus 5 such as data issued from the BIOS 4 and which is normally directed  
18 through the bus 5 to a display adapter and to a local video display, if displayed at  
19 all. Examples of such displayed data include display adapter diagnostics, amount  
20 of installed RAM 3, boot or fixed disk parameters, CD-ROM driver installation, and  
21 information regarding BIOS settings (See Fig. 4).

22           Video output of primary interest and which is written to the  
23 administration adapter 10 is display data, textual in the case of an MDA adapter

1 which, which is formatted according to the text mode set by the system board 1 and  
2 compatible with text modes available on the administration adapter 10. In its most  
3 elementary form, the administration adapter emulates an MDA (monochrome  
4 display) adapter having only one format; text normally displayed at 80 characters by  
5 25 lines (80x25). For a VGA (video graphics) and later adapters, besides having  
6 greater graphical capability, provide the capability for other text modes, one of  
7 which is 132 characters by 60 lines (132x60).

8                Optionally, data communicated between the administration adapter 10  
9 and the remote console 9 can include graphical data, coordinate and state data.  
10 Graphical data can be communicated and displayed to the remote user as graphical  
11 data at the console 9, or graphical character data can be recognized, and  
12 communicated as text.

13                For a BIOS 4 used in conjunction with an ISA bus 5, functional  
14 emulation of the MDA adapter is achieved by emulating video RAM 13 of frame  
15 buffer and video controller I/O registers.

16                Specifically, the administration adapter 10 comprises a bus connector  
17 12 and dual port RAM 13 for storing the frame buffer and I/O registers.  
18 Conventional serial communications hardware comprises a bus-recognized 16550  
19 UART 14, a DUART 15 connected to a DB-9 RS-232 serial output connector. A first  
20 microprocessor 16 controls monitoring of the dual port RAM for bus writes, reads  
21 any written data and analyses it. In one embodiment, the first microprocessor 16  
22 extracts textual display data from the dual port RAM 13 and converts it to a form  
23 suitable for transmission in some form via the UART/DUART 14,15 and to the

1 remote console 9. A PC-reset relay 17 is controlled by microprocessor 16 and is  
2 hardwired to the system board reset 8. A serial debug port 18 is provided for  
3 adapter diagnostics.

4           A second microprocessor 20 is provided for specifically converting  
5 data received from the remote console 9 into emulated commands which are  
6 recognized by the PC-Server's input interface as commands. Graphical data or  
7 graphical user interface data (such as through a pointing device or mouse) received  
8 by the administration adapter can be recognized for extracting instructions directed  
9 to the administration adapter. Such extraction can comprise implementing  
10 command instructions such as character recognition for extracting textual data or a  
11 lookup table data corresponding to mouse coordinate and mouse-click state data.

12           In one simple embodiment, the second microprocessor 20 specifically  
13 converts received data to emulated keyboard commands such as scan codes  
14 recognized by the system board keyboard input device 7. In the simplest case, the  
15 scan codes are conducted to the system board via cable 21 to keyboard port as an  
16 input interface 6. In another embodiment, received data is converted for emulating  
17 commands which are recognized by other input interfaces such as the PS-2  
18 interface, USB (universal serial bus), the PCI bus itself or a mouse interface.

19           The corresponding RAM 13 memory locations for this MDA emulating  
20 adapter occupy 4K bytes of dual-port video RAM occupying addresses 0xb0000-  
21 0xb0fff. The administration adapter 10 does not need to use all of the MDA I/O  
22 registers such those used for video display synchronization, video status or parallel  
23 printer interfacing. More particularly, administration adapter 10 emulates two bytes

1 of registers at port addresses 0x3b4 and 0x3b5, specifically being for the adapter's  
2 6845 CRT controller. The 6845 CRT controller occupies two bytes in the bus I/O  
3 space, but contains 18 data registers, each accessible by first writing the register's  
4 address into the "CRTC address register", then reading/writing the data to/from the  
5 selected register via the "CRTC data register". The 6845's registers include video  
6 timing control (write-only), cursor address MSB (read/write), cursor address LSB  
7 (read/write), and light pen location (read-only). Of these, only the cursor address  
8 registers are relevant for providing sensory feedback capability to the remote user.  
9 The administration adapter 10 makes the registers at 13 available to the first  
10 68HC11 microprocessor 16.

11               The bus 5 writes textual display data to the frame buffer, identified as  
12 being at the dual port memory or RAM 13 located on the administration adapter 10.  
13 Dual port RAM 13 permits the system board 1 to write the data while the adapter 10  
14 simultaneously polls the data to see if any character in a line of 80 characters has  
15 changed since the last poll. The administration adapter 10 performs MDA  
16 emulation by trapping frame-buffer writes to the MDA's address space, calculating  
17 console screen coordinates, within the 80x25, based on the address and converting  
18 that data capable of serial transmission. One data form is standard ANSI (e.g. VT-  
19 100) escape sequences. Character attributes such as blink, highlight, and underline  
20 are also converted to escape sequences. Thus the 80 character line, with attributes,  
21 actually requires 160 bytes of information. Ultimately, these escape sequences, in  
22 addition to the actual character data, are sent to the remote user console 9.

1           The first microprocessor 16, such as the Motorola M68HC11 HCMOS  
2 single-chip computer ("68HC11") controls the adapters reading from, and possible  
3 writing operations to, the frame buffer. By providing a video update register 19,  
4 overhead on the 68HC11 microprocessor 16 is reduced by detecting writes by the  
5 bus 5 to the MDA frame buffer 13 without reading the whole frame buffer. Each bit  
6 corresponds to one line of characters on a video display. Any bus write to the frame  
7 buffer sets the bit in the video register corresponding to that line. Reading a byte  
8 clears that byte.

9           Further, for additional debugging capability, the administration adapter  
10 10 emulates an additional I/O port 0x80 on the bus 5. When a PC-Server exits  
11 reset and executes the contents of its BIOS 4, the startup sequence generally  
12 includes a number of hardware diagnostic tests. At the beginning and end of each  
13 test a byte (the "Power On Self Test", or "POST" byte) is output to port 0x80  
14 indicating the progress of the tests. Should a test in the sequence fail, the  
15 sequence is halted and the last byte written to the POST port remains as an  
16 indicator of the cause. The administration adapter 10 monitors bus writes to this  
17 port 0x80 and retains the most recently written byte (last POST byte) for the remote  
18 user. The last POST byte written in a successful startup will normally be 0x00.

19           For implementing VGA and higher adapter emulation including  
20 graphics recognition, different RAM capability and greater microprocessing  
21 capability would likely be required.

22           The conventional output escape sequences are sent via serial  
23 communications to the remote user. The preferred interface is a PC compatible

1 serial RS-232 controller, such as a ST16C550 UART from Exar Corporation. Note  
2 that other and higher speed serial devices, such as USB , Ethernet or other  
3 broadband network interfaces are known and are similarly adaptable for this use.

4           The UART 14 is a serial communications device to and from the RS-  
5 232 port 15b. The serial device is address and interrupt configurable to the industry  
6 standard COM ports. As stated in a character and keyboard emulation  
7 embodiment, the serial device 14,15,15b outputs console data to the remote user  
8 and receives emulated keyboard data therefrom. In the simplest case, the serial  
9 communications passes all received data to the PC-Server.

10           Alternatively, the administration adapter's onboard 68HC11  
11 microprocessor 16 monitors each character received by the serial communications  
12 15b,15,14 to determine if the keyboard input communication should be passed  
13 through to the PC-Server, or if an attention command sequence is received for  
14 conducting administration adapter specific operations. Accordingly, a Philips  
15 Semiconductor SC26C92 Dual Universal asynchronous receiver/transmitter (a  
16 DUART) 15 is employed, substantially being dual UARTS. Further, modem  
17 registers 25 are stored so that the administration adapter 10 can monitor the six  
18 standard modem control signals (RI, DCD, DRS, DTR, CTS AND RTS) and pass  
19 through or override the default modem register settings provided by the remote  
20 devices.

21           Keyboard command inputs to the PC-Server are received as  
22 command data from the serial port 15b, and if it is to be passed through, mapping it  
23 to, or emulating, PC keyboard scan-codes. The second microprocessor 20 controls



1 the keyboard output to the PC-Server's input interface 6. A suitable microprocessor  
2 20 is the Atmel Corporation, AT90S4433, known as an AVR. The scan codes are  
3 output to the keyboard interface 6. The connection between the administration  
4 adapter 10 and keyboard interface 6 is usually through an electrical cable connector  
5 21 to the system board keyboard input interface 6 (or DIN jack in this instance), but  
6 it also known to include infrared (IR), various bus or hardware interfaces such as  
7 mouse or USB port interfaces,.

8           The keyboard interface 6 permits remote user intervention or input to  
9 the PC-Server through this keyboard emulation. If desired, the administration  
10 adapter 10 functions to merely to pass remote user keyboard scan codes to the PC-  
11 Server. The serial interface simply passes character output to the remote user and  
12 accepts and passes on emulated keyboard commands to the keyboard input  
13 interface of the PC-Server.

14           However, preferably, the administration adapter 10 has advanced  
15 function capability, such as having the ability to variably reset or suspend the PC-  
16 Server, alter the emulation or get the keyboard status, if is necessary to distinguish  
17 commands which should interpreted as being destined for the PC-Server or locally  
18 for the administration adapter.

19           To get the attention of the administration adapter, the serial device  
20 listens for a predefined or user-defined character. Typically, such a character is one  
21 which is not regularly used by the PC-Server or application program. Even if the  
22 attention character has both a local attention function and a PC-Server function,  
23 repeating of the attention character will pass it through to the PC-Server.

1                   One function of the administration adapter 10 which is accessible  
2 through and attention character is the ability to reset the PC (Figs. 3,4). While it is  
3 possible also to pass through a soft reboot command using the ubiquitous  
4 <ctrl><alt><del>, occasionally the PC-Server is so messed up that a hardware  
5 reboot is required. The administration adapter 10 is provided with a PC-reset 17  
6 which provides a mechanical relay contact closure hard-wired 22 to a PC-reset on  
7 the system board 1. Optionally, with the newer ATX-type system boards, the  
8 administration adapter can perform a power cycle reset.

9                   The administration adapter 10 is further enhanced if it can be  
10 configured to provide added functionality to the remote user. Normally, the  
11 administration adapter 10 works transparently, passing data back and forth between  
12 the remote user and the PC-Server. For simplicity, this description is set forth in the  
13 context of character data between the PC-Server and the remote console 9. In  
14 order to communicate local controls to the administration adapter 10, the remote  
15 user must send a specified attention character. Due to the low probability of having  
16 a duplicate function at the PC-Server, the default for the attention character is ASCII  
17 0x1e (<control><^> or <control><~>), but may be altered by the user. Upon receipt  
18 of the attention character, the administration adapter responds by prompting the  
19 user for a command, as shown in Fig. 2.

20                   In order to provide this local adapter configuration capability, the  
21 administration adapter 10 further comprises two code stores: a non-volatile EPROM  
22 bootloader 30 and a FLASH memory 31 partitioned into four blocks for storing the  
23 board's operating code. Additional RAM 31 is provided for the first microprocessor

1 16 and EPROM 30. Having reference to Fig. 5, when the administration adapter is  
2 powered up with the PC-Server, (or reset) the bootloader reads the header of each  
3 FLASH partition, determines if any contain boot images, and if any are marked as  
4 the "default boot" image. This information is presented to the user via the serial  
5 console port. The bootloader then proceeds to count down approximately five  
6 seconds, during which the remote user may accept the default boot, interrupt to  
7 select a different boot image or wait out a five second countdown timer using input  
8 commands <return>, <esc>, or by typing nothing at all. Typing <return> truncates  
9 countdown timer and causes the administration adapter to immediately boot the  
10 default image. Typing <esc> invokes the bootloader's FLASH programming  
11 routines, preparing the administration adapter to accept a new operating image from  
12 the remote user. Should <esc> be typed inadvertently, the user simply types  
13 <return> to boot the default image (as though <esc> had never been pressed) or  
14 specify booting a non-default image. Typing nothing at all causes the administration  
15 adapter to boot the default image at the conclusion of the five second countdown.

16 Different boot images can contain different configurations including  
17 settings for serial port configurations and alternate keyboard emulation mapping.

18 Once a boot image has been selected, use of the attention character  
19 signals the administration adapter to exit emulation mode and await commands  
20 from the user. For instance, the user may issue a command or press <?> or <h>  
21 and be rewarded with a help screen as shown in Figure 2. Issuing an <r> ("reset")  
22 causes the reset to be asserted for a period of 500ms, then released. Issuing an <i>  
23 ("in") causes the reset to be asserted and held in the asserted state until the user

1 issues an <o> ("out") command, releasing the reset and allowing the PC-Server to  
2 boot. This allows a remote user to take the machine offline by brute-force means  
3 and keep it there indefinitely. A keyboard status inquiry can be made by issuing  
4 an ^x which then queries the keyboard emulation as to its state. This is primarily  
5 useful for debugging system problems, and is not of much interest if the system is  
6 behaving itself. A ^l command causes the administration adapter 10 to redraw the  
7 display, useful in the event that the display becomes out of sync with the MDA  
8 emulation due to an event such as line noise.

9                Sometimes, the keyboard commands accepted by the PC-Server are  
10 not available on the remote user's keyboard, e.g. <alt>. Accordingly, the  
11 administration adapter 10 can send a specific key or combination of keys to the PC  
12 using a mnemonic scheme.

13              A PC keyboard utilizes keys that, while being normally thought of as  
14 modifiers for other keys (such as <shift>, <control>, and <alt>) in fact generate their  
15 own output codes even when not used in conjunction with any other keys. Thus, in  
16 order to comprehensively emulate the PC keyboard's behavior, the administration  
17 adapter 10 provides for the use of these keys in both contexts - either as modifiers  
18 or alone. Thus, upon entering the Attention Character and the command <x>, the  
19 user is prompted for the keys to be output.

20              Fig. 7 lists the supported keys and their associated mnemonics.  
21 Additionally, Fig. 7 lists the mnemonics for the <shift>, <control>, and <alt> keys as  
22 appropriate for their use as modifiers.

1           Typing the mnemonic outputs the appropriate key code to the  
2 keyboard interface. Only one key may be output per operation. Entering the  
3 mnemonics for more than one key returns an error message. For instance, to send  
4 <NUM LOCK>, the user types: <Attention Character> <x> <n> <u> <m> <l> <k>  
5 <return>.

6           Any number of modifier keys (from one to six) may be used at a time  
7 to modify the key being. To send <Left Shift><Function 12>, type <Attention  
8 Character> <x> <S> <-> <f> <1> <2> <return> and to reboot the PC, type:  
9 <Attention Character> <x> <c> <-> <a> <-> <d> <e> <l> <return>

10           Other commands are available relating to functions one can ask the  
11 adapter to execute. The administration adapter 10 maintains the user-customizable  
12 configuration information in the non-volatile EEPROM 30.

13           Having reference also to the table in Fig. 8, a <c> command invokes  
14 the configuration menu, allowing the user to change selected parameters. The  
15 configuration menu is exited by pressing the <esc> key, at which time any changes  
16 made are committed.

17           An <m> command accesses the message buffer. Some  
18 administration adapter device drivers supply warning or error messages. These  
19 messages are logged in a 1Kbyte ring buffer. The contents of the message buffer -  
20 the most recent 1024 bytes logged - can be viewed using this m command. These  
21 messages are also transmitted out the optional debug RS-232 port.

22           The <p> command access the last POST byte. When a PC exits  
23 reset and executes the contents of its BIOS, the startup sequence generally

1 includes a number of hardware diagnostic tests. At the beginning and end of each  
2 test a byte is output to port 0x80 indicating the progress of the tests. Should a test in  
3 the sequence fail, the sequence is halted and the last byte written to the POST port  
4 remains as an indicator of the cause. The administration adapter monitors bus  
5 writes to this port and retains the most recently written byte for the user. The last  
6 byte written in a successful startup will normally be 0x00. If this is the case, the <p>  
7 command will return the word "Nothing". POST codes are specific to the BIOS  
8 manufacturer.

9           A <q> command quits the administration adapter. This command  
10 allows the user to force the administration adapter to begin execution of the  
11 bootloader EPROM code as though it were just reset. This is primarily useful to  
12 those developing code for the board, as it provides a method of exiting the normal  
13 operating code and entering either the bootloader or the RS-232 debug monitor,  
14 depending on the setting of the memory map. If configured to "Reset PC on boot",  
15 executing this command will cause the administration adapter to reset the PC-  
16 Server.

17           As discussed above and in Fig. 5, the administration adapter 10 first  
18 executes bootloader routines when the administration adapter 10 is reset, either  
19 manually or upon power-up. After initialization, the bootloader counts down a five-  
20 second delay, at the conclusion of which (assuming the user does not intervene) the  
21 bootloader will identify and commence execution of the default software image. A  
22 "Reset PC on Boot" configuration option allows the user to control the startup  
23 sequence of the administration adapter and the PC-Server. If this option is set to

1 YES, the bootloader places - and holds - the PC-Server in reset as soon as the  
2 administration adapter comes out of reset. Once the administration adapter is up, it  
3 releases the PC's reset and allows the PC-Server to boot. This ensures the user is  
4 able to monitor the entire boot sequence. It also allows the user an arbitrary amount  
5 of time to perform configuration operations on the administration adapter while  
6 delaying the PC-Server's boot.

7           Selecting YES also causes the bootloader to force the PC-Server PC  
8 into reset if the user uses a "q - Quit to ROM" command to exit the administration  
9 adapter's operating software and enter the bootloader. Conversely, selecting NO  
10 allows the PC-Server to boot regardless of the operational state of the  
11 administration adapter, and allow the user to exit to the bootloader without forcing  
12 the PC-Server into reset, desirable in the event that the user wishes to load a new  
13 operating image into the administration adapter's FLASH without bringing down a  
14 running PC-Server.

15           The administration adapter's two basic modes of operation are:

- 16           • an emulation mode, in which characters written into the video  
17           frame buffer by the PC-Server bus are converted to serial data  
18           and transmitted to the remote user, and input received from the  
19           user is presented to the PC-Server as though originating from a  
20           local input interface such as a keyboard; and
- 21           • Serial Pass-through mode, in which the PC-Server  
22           communicates bidirectionally via the administration adapter's  
23           onboard 16550, with data passed back and forth between the

1                   PC-Server and the remote user by the administration adapter's  
2                   microprocessor.

3                   To the PC-Server, the administration adapter represents two distinctly  
4   separate I/O devices: serial communications and a video board. This means that  
5   although the board has two channels capable of simultaneously generating  
6   outbound data destined for the user, there is only one channel via which that output  
7   can be directed to the remote user - the RS-232 port.

8                   By default (that is, with Serial Pass-through mode disabled by setting  
9   it to "NO" in the Configuration menu) the administration adapter operates in  
10   Emulation mode only. The MDA and keyboard emulations are in full-time operation,  
11   and although the 16550 UART, if enabled, is available to the PC-Server's bus, its  
12   serial I/O is disconnected from the outside world. If Serial Pass-through mode is  
13   enabled (ie set to "YES" in the Configuration menu) the administration adapter  
14   monitors the 16550 UART for activity, and upon detecting a character output from  
15   the 16550 UART exits emulation mode and begins to relay characters between the  
16   16550 UART and the RS-232 connector.

17                  Conversely, if the administration adapter 10 is operating in Serial  
18   Pass-through mode and detects data written to the MDA buffer, it disconnects the  
19   16550 UART's serial I/O and switches back to emulation mode.

20                  In either mode the administration adapter continues to monitor the  
21   data stream input by the user and brings itself online upon detection of the attention  
22   character.



1               This is an arrangement that allows for the greatest possible flexibility  
2 and user choice in determining how the PC-Server's console appears to its  
3 operating system, while ensuring that a functional console is always available on a  
4 machine that has crashed down to the BIOS.

5               Some optimizations are performed on video-emulation data by the  
6 local processor. For example, the generation of unnecessary cursor addressing  
7 information is suppressed for writes to adjacent/consecutive video RAM locations.  
8 Although the video-to-serial emulation is complete and usable at all levels of  
9 machine operation, it is primarily designed for sub-OS use; that is, for motherboard  
10 and peripheral BIOS configuration and bootstrap monitoring.

11              The emulation, though proper, carries high local overhead and is  
12 accordingly slow. It is thus intended that once the user's OS is running, it can invoke  
13 a standard COM-port serial console application. This transition is made seamlessly  
14 on the emulator board by toggling the RS-232 connector's data path from the video-  
15 emulator's output to the UART's output upon detection of writes to the UART's  
16 transmit register (and back again if MDA video space is written to).

- 17              a) System power-on; administration adapter comes out of reset in  
18 emulation mode.
- 19              b) A write is made to MDA space by the BIOS. Data written to video  
20 memory is converted to serial output.
- 21              c) BIOS goes through normal boot sequence, continuing to send data  
22 to the MDA admin adapter. At this point the user may interrupt the  
23 normal boot sequence for purposes of configuration.

1                   d) BIOS loads operating system bootblocks. These are compiled for  
2                   serial output. Bootblocks write data to the serial port address; the  
3                   adapter disconnects the RS-232 connector from video emulator's  
4                   serial output and connects it to the onboard 16550 UART. All  
5                   input/output is exactly as it would be with a standard PC serial port.

6                   e) Operating system loads and runs in serial console mode.

7                   f) Operating system is rebooted. System resets, goto (b).

8                   It is conceivable that the PC-Server may hang without an  
9                   administrator user being aware or available to take corrective action. For these  
10                  situations it is useful to employ a watchdog timer so that the administration adapter  
11                  can to detect such failures and automatically reboot the PC-Server. Accordingly, a  
12                  suitable software hook is implemented on the PC-Server and is monitored by the  
13                  interface. For instance, the operating system kernel can be modified or a  
14                  background application process provided for periodically generating a watchdog  
15                  character sequence written to the MDA frame buffer. If the significant sequence is  
16                  not received within a predetermined time, then the administration adapter can deem  
17                  the PC-Server to be unstable or locked-up and accordingly cause the PC-Server to  
18                  reboot.

19                  Note that in Windows NT (Microsoft Corporation) operating systems, a  
20                  video adapter must be present else the system will not operate. Hence, it is likely a  
21                  monitor is also provided and, if so, then a local keyboard is likely also available.  
22                  The administration adapter then must co-exist with the NT video adapter and be  
23                  restricted to receiving write-only commands from the bus functions (the

1 administration adapter eavesdrops only) to avoid conflict with the NT video adapter.  
2 Further, the hardwired input interfaces, such as keyboard connectors must permit  
3 flow-through of the local interface scan codes until such time as a write to the frame  
4 buffer is character detected at which time emulated input from the administration  
5 adapter is given priority.

6           In a further application, the administration adapter can be used to  
7 implement a text to speech system for assisting blind users and system  
8 administrators. The way things are now, blind users tend to use speech  
9 synthesizers with their computers. Special drivers are installed at the operating-  
10 system level to convey information displayed on the video hardware to the speech  
11 synthesizer. Again, though, these drivers are not active when the machine is at the  
12 BIOS or booting, leaving the blind user quite unable to observe boot (or boot failure)  
13 status. Having an administration adapter in the system and directing the screen  
14 data out the serial port provides a means for the user to get that data to serial  
15 speech-synthesis hardware.